



# **PARTICLE COUNTERS AND WAFER MANUFACTURING IN A SEMICONDUCTOR CLEANROOM.**

---

Lighthouse Worldwide Solutions



## Overview

---

Microchips are at the heart of modern electronics, powering everything from smartphones and computers to cars and medical devices. These tiny devices, also known as integrated circuits, contain millions or even billions of transistors and other electronic components that are interconnected on a single piece of silicon called a wafer. The process of manufacturing these microchips is a complex and highly specialized process that involves a series of steps, each of which is critical to the final product's quality, performance, and cost-effectiveness. Particle Counters are used to monitor environmental contamination and product contamination and play a key role in product quality and yield.

In this article, we will provide a detailed overview of the microchip manufacturing process, including the different stages involved, the equipment used at each step, and the key challenges and considerations that must be addressed to achieve success in this highly competitive and rapidly evolving industry.

Whether you are new to microchip technology or an experienced engineer looking to deepen your knowledge, this article will provide a comprehensive introduction to this fascinating and essential field of that process and highlight where particle counters assist in the process.



**Cleanroom Operator inspecting silicon wafer.**

## Overview of the Microchip Manufacturing Process

The microchip manufacturing process consists of a series of sequential steps, each of which is designed to transform a blank wafer into a finished microchip containing millions or billions of transistors and other electronic components. These steps typically include:

### 1. Wafer Preparation

The first stage of the microchip manufacturing process is wafer preparation, which involves cleaning and polishing the surface of the silicon wafer to remove any particles or impurities that could interfere with subsequent processing steps. This is typically accomplished using a series of chemical and mechanical processes that are designed to minimize the presence of contaminants and improve the flatness and uniformity of the wafer surface.



### **Wafer ingot seed and cut, polished wafers.**

One of the key challenges in wafer preparation is the control of particle contamination. Even tiny particles, such as dust or debris, can have a significant impact on the quality and yield of the finished devices, as they can cause defects or errors in the processing steps that follow. To address this challenge, wafer preparation is typically carried out in a specialized facility called a cleanroom, which is designed to maintain a high level of cleanliness and minimize the presence of contaminants.

In addition to particle contamination, wafer preparation must also address issues related to surface roughness, flatness, and uniformity. These factors can have a significant impact on the quality and performance of the finished devices, as they can affect the deposition and etching processes that follow. To address these challenges, wafer preparation typically involves a combination of chemical cleaning, polishing, and rinsing steps that are designed to remove surface contaminants, smooth the wafer surface, and improve its uniformity and flatness.

## **2. Photolithography**

The second stage of the microchip manufacturing process is photolithography, which involves using light to transfer a pattern onto the surface of the wafer. This pattern serves as a guide for subsequent processing steps, allowing the fabrication of complex structures such as transistors and interconnects.

Photolithography is carried out using a specialized machine called a stepper, which uses a series of lenses and mirrors to focus a beam of light onto the wafer and expose it to the desired pattern. The pattern is typically created using a mask, which is a photographic negative of the desired pattern that is placed between the light source and the wafer.


One of the key challenges in photolithography is the control of the exposure process, as variations in the intensity or duration of the exposure can have a significant impact on the quality and accuracy of the pattern. To address this challenge, photolithography typically involves a series of calibration and verification steps that are designed to ensure that the exposure process is consistent and accurate.

Another key challenge in photolithography is the creation of high-resolution patterns. The resolution of the pattern is limited by the wavelength of the light used, as well as the quality of the optics and the mask. To achieve ...high-resolution patterns, a process called "optical proximity correction" is used to compensate for the distortion that occurs when the pattern is transferred onto the wafer. This involves adjusting the shape of the pattern to account for the diffraction and interference effects that occur during the exposure process, allowing for more accurate and precise pattern replication.

After the wafer has been exposed to the pattern, it undergoes a development step that removes the exposed or unexposed regions of the photoresist, leaving behind a patterned layer that can serve as a mask for subsequent processing steps.



**Photolithography masks in containers.**



**Photolithography process.**


### 3. Etching

The third stage of the microchip manufacturing process is etching, which involves removing material from the wafer surface to create the desired structures. This can be done using a variety of techniques, including wet chemical etching, dry plasma etching, or a combination of both.

Wet chemical etching involves immersing the wafer in a solution of acid or other chemicals that selectively dissolve the exposed regions of the wafer surface. This process can be used to create precise patterns or features with high aspect ratios, but it can also result in undercutting or other undesirable effects if not carefully controlled.

Dry plasma etching, on the other hand, uses a high-energy plasma to selectively remove material from the wafer surface. This process offers greater control over the etching process and can be used to create more complex or intricate patterns, but it can also result in damage to the wafer surface if not carefully controlled.

After the etching step is complete, the wafer is typically cleaned and rinsed to remove any remaining photoresist or etching residues.



**The etching process uses a plasma gas to etch the wafer.**

### 4. Deposition


The fourth stage of the microchip manufacturing process is deposition, which involves adding material to the wafer surface to create the desired structures or features. This can be done using a variety of techniques, including physical vapor deposition (PVD), chemical vapor deposition (CVD), or electroplating.

PVD involves heating a material to a high temperature and allowing it to condense onto the wafer surface, creating a thin film of the desired material. This process is typically used to deposit metals or other conductive materials onto the wafer surface.

CVD, on the other hand, involves introducing a gas or vapor containing the desired material into a chamber containing the wafer, where it reacts to form a thin film on the wafer surface. This process is typically used to deposit insulating or semiconducting materials onto the wafer surface.

Electroplating involves using an electric current to deposit a thin film of material onto the wafer surface. This process is typically used to create thicker films or to deposit materials that are difficult to deposit using other techniques.


After the deposition step is complete, the wafer is typically cleaned and rinsed to remove any remaining deposition residues.



**Schematic of physical vapor deposition for Tungsten coating.**

## 5. Planarization

The fifth stage of the microchip manufacturing process is planarization, which involves smoothing and flattening the wafer surface to improve the uniformity and reliability of the finished devices. This is typically done using a technique called chemical mechanical planarization (CMP), which involves using a slurry of abrasive particles and chemicals to remove material from the wafer surface and create a flat and smooth surface. Planarization is critical to the success of the microchip manufacturing process, as it can help to reduce defects, improve yield, and enhance the performance of the finished devices.



**Chemical Mechanical Planarization (CMP) process.**




## 6. Metallization

The sixth stage of the microchip manufacturing process is metallization, which involves adding metal layers to the wafer surface to create interconnects that allow the various components of the microchip to communicate with one another. This is typically done using a technique called sputtering, which involves bombarding a metal target with high-energy particles to release atoms of the desired metal, which then condense onto the wafer surface to form a thin film.

The metallization step is critical to the functionality of the finished microchip, as it allows the various components of the chip to communicate with each other and with the outside world.

### METAL CONNECTIONS BETWEEN LAYERS OF A SILICON WAFER.




**Cross-section diagram of silicon wafer with metal connection layers.**

## 7. Testing and Packaging

The final stages of the microchip manufacturing process involve testing and packaging the finished devices. This typically involves a series of tests to ensure that the devices meet the desired specifications and perform as expected.

Once the devices have been tested, they are packaged into a variety of formats, including plastic or ceramic packages, depending on the intended application. The packaging process involves encapsulating the microchip in a protective casing, which can include wire bonds or other interconnects to allow the chip to be mounted onto a printed circuit board or other substrate.



**Internal view of an IC chip enclosed in packaging.**

# Particle Counters in Semiconductor Industry

Particle counters are an essential tool in the semiconductor manufacturing process as they are used to monitor the level of contamination in the cleanroom environment. Contamination can come from a variety of sources, such as particles generated by the wafer processing equipment or by personnel working in the cleanroom.

Particle counters work by measuring the number and size of particles in the air, which are typically measured in terms of the number of particles per cubic meter. These measurements can be used to determine the level of contamination in the cleanroom, which is critical to maintaining the high levels of cleanliness required for successful semiconductor manufacturing.

During the fabrication process, the wafer is moved from one processing step to another through a series of tools and equipment located within the cleanroom. Each time the wafer is exposed to a new processing step, there is a risk of introducing contamination, which can have a significant impact on the yield and performance of the final microchip.

Particle counters are typically used to monitor the cleanliness of the cleanroom environment at various stages of the fabrication process. For example, they may be used to monitor the level of airborne particles generated during the wafer polishing process or during the deposition of thin films onto the wafer surface.

By monitoring the level of contamination in the cleanroom environment, semiconductor manufacturers can take steps to reduce the risk of introducing defects into the microchip. This can include measures such as increasing the airflow within the cleanroom, increasing the frequency of equipment maintenance, or increasing the frequency of personnel gowning and decontamination procedures.

In addition to monitoring the cleanliness of the cleanroom environment, particle counters can also be used to monitor the quality of the wafer surface itself. For example, they can be used to detect the presence of particles on the wafer surface that may have been introduced during the handling or processing of the wafer.

# Conclusion

The microchip manufacturing process is a complex and highly specialized process that involves a series of intricate steps to create the tiny structures and components that make up modern electronics. From the initial design and layout of the chip to the final testing and packaging, each stage of the process requires careful attention to detail and a deep understanding of the physics and chemistry involved.

Despite the challenges involved, advances in microchip manufacturing have revolutionized the modern world, enabling a wide range of applications in fields ranging from communications and computing to healthcare and transportation. As the demand for faster, more powerful, and more energy-efficient electronics continues to grow, the microchip manufacturing process will continue to play a critical role in shaping the future of technology.

Overall, particle counters play a critical role in the semiconductor manufacturing process, enabling manufacturers to maintain the high levels of cleanliness required for successful microchip fabrication. By providing real-time monitoring of the cleanroom environment, they help to ensure that the finished microchips meet the stringent quality and performance standards required for modern electronics applications.